



R series Module-level Micro controller
(Module-level Rapid Shutdown Device)

INSTALLATION GUIDE



The Installation and Verification of V2.5 System Control (Solution R)

Installation and Verification
of R Series Micro Controller



Installation and Verification
of V2.5 Control Box DCON-S




Solution R
System Setting

Note: Please strictly follow this guide for installation and operation, otherwise the performance and warranty may be affected by some wrong operations.

1. Product Introduction

① APT-MC-R-T1 (hereinafter referred to as R-T1) has 4 wires, namely IN+ IN- (Input) and OUT+ OUT- (Output)





① IN- Negative Input (to panel)

③ IN+ Positive Input (to panel)

② OUT- Negative Output (to adjacent R-T1)

④ OUT+ Positive Output (to adjacent R-T1)


⚠ Red casing on the OUT terminals





① Back hook

② Back clamp

- 2 APT-MC-R-T2 (hereinafter referred to as R-T2) has 6 wires, namely PV1+ PV1- (Input) , PV2+ PV2- (Input) , and OUT+ OUT- (Output)




- 1 PV1+ Positive Input (to panel 1)
 - 2 PV1- Negative Input (to panel 1)
 - 3 OUT- Negative Output (to adjacent R-T2)
 - 4 PV2- Negative Input (to panel 2)
 - 5 PV2+ Positive Input (to panel 2)
 - 6 OUT+ Positive Output (to adjacent R-T2)
- ! Yellow casing on the PV1 terminals; White casing on the PV2 terminals; Red casing on the OUT terminals




- 1 Back hook
- 2 Back clamp

2. Installation Requirements

- ❶ Ensure that the installation position is well ventilated



- ❷ The distance is $\geq 25\text{mm}$ from the roof




- ❸ It is prohibited to cut the cable.
- ❹ The cable length between the farthest R-T1/R-T2 and the control box shall not exceed 400M.
- ❺ When there are more than one strings parallel inputs under the same MPPT, there are the following limitations when configuring the R-T/R-T2: photovoltaic strings connected to the same MPPT must use the same model and quantity of panels and R-T1/R-T2, and must be fully installed with R-T1/R-T2. The orientation and angle of all panels of strings
- ❻ Must comply with the specified parameters of R-T1/R-T2.
- ❼ If a string is severely shaded, please connect this string to a separate MPPT of the inverter.
- ❼ Please take protective measures and ensure that the DC side of the inverter and the power supply of the control box are turned off before installation.
- ❽ It is recommended to install the microcontrollers in a low-light environment .


3. Installation Procedures

1 Select the appropriate method to install based on the actual situation


Method A: Secure R-T1/R-T2 on the frame of panels



Method B: Secure R-T1/R-T2 on the mounting bracket



Method C: Buckle R-T1/R-T2 on the frame of panels




2 Connect micro controller and panels according to the wiring diagram

2.1 R-T1 wiring

⚠ Ensure that R-T1 wiring is correct, otherwise the devices may be damaged


Connect input wires to the panel, and output wires to that of the adjacent R-T1



2.2 R-T2 wiring


⚠ **Ensure that R-T2 wiring is correct, otherwise the devices may be damaged**

Connect R-T2 input wires (PV1) to the panel 1, input wires (PV2) to the panel 2, and output wires to that of adjacent R-T2.



How to connect a R-T2 to a single panel?


Only need to connect PV2 input wires to the panel, and connect PV1 +- (yellow) with each other.





4. Installation Verification

2 Verify the R-T1 wiring


⚠ Ensure that R-T1 wiring is correct, otherwise the devices may be damaged



The measured output voltage of each single R-T1 should be less than 1V





The measured output voltage of each string should be less than 30V



2 Verify the R-T2 wiring

⚠ Ensure that R-T2 wiring is correct, otherwise the devices may be damaged



Contact us

If you have any technical questions on AdvanSol products, or need other language files, please contact us for help.

AdvanSol Power Technology Co.,Ltd

8 Floor, Building 2, 36 Zijing Street, Wuzhong District,
Suzhou City, China

☎ +86-512-662352

🌐 www.advansol-power.com

✉ service@advansol-power.com



Friendly reminder: Please scan the QR code to access versions in other languages.